




Elementary Statics

Parallelogram Law of Vector Addition

- The most basic way to add two vectors is a **geometric approach** called the **parallelogram law of vector addition**.
- The **sum** of the two vectors is called the **resultant**.
- Consider the two forces \tilde{F}_1 and \tilde{F}_2 acting on the support as shown in the diagram. The total force acting on the support is found by **adding** the two vectors.
- By placing the tails of the vectors at the same point, we can **construct** the resultant $\tilde{F} \triangleq \tilde{F}_1 + \tilde{F}_2$ by forming a **parallelogram** as shown in the diagram below on the left. By placing the tail of the second vector at the head of the first, we can construct the resultant by forming a **triangle** as shown in the diagram on the right.



Parallelogram formed by \tilde{F}_1 and \tilde{F}_2



Triangle formed by \tilde{F}_1 and \tilde{F}_2

- In general, the triangle formed by \tilde{F}_1 , \tilde{F}_2 , and the resultant \tilde{F} is a **non-right triangle**. The lengths and angles within this triangle can be related using the **law of cosines** and the **law of sines**.



Example #1:

Given: Two forces in the diagram

Find: \tilde{F}_R the resultant force

Solution:

Geometric construction:




Applying the **law of cosines** and **law of sines** to the diagram above gives.

$$\text{Law of Cosines: } \tilde{F}_R^2 = 150^2 + 100^2 - 2(100)(150)\cos(80) \approx 27290.6$$

$$\Rightarrow \boxed{\tilde{F}_R \approx 165.199 \approx 165 \text{ (lb)}}$$

$$\text{Law of Sines: } \frac{\sin(\theta)}{100} = \frac{\sin(80)}{\tilde{F}_R} \Rightarrow \boxed{\theta = \sin^{-1}\left(\frac{100\sin(80)}{\tilde{F}_R}\right) \approx 36.5937 \approx 36.6 \text{ (deg)}}$$

Result: \tilde{F}_R is a 165 (lb) force acting at 56.6 (deg) relative to the X direction.





Example #2:

Given: $|\mathbf{F}| = 200$ (lb) is oriented as shown in the diagram

Find: F_u and F_v the components of \mathbf{F} along the u and v directions

Solution:

Geometric construction:



As drawn, $\mathbf{F} = \mathbf{F}_u + \mathbf{F}_v$. Using the **law of sines**, write

$$\frac{F_u}{\sin(40)} = \frac{F_v}{\sin(20)} = \frac{F}{\sin(120)}$$

$$\Rightarrow F_u = \left(\frac{\sin(40)}{\sin(120)} \right) F = \left(\frac{\sin(40)}{\sin(120)} \right) 200 \approx 148.445 \approx 148 \text{ (lb)}$$

$$\Rightarrow F_v = \left(\frac{\sin(20)}{\sin(120)} \right) F = \left(\frac{\sin(20)}{\sin(120)} \right) 200 \approx 78.9862 \approx 79.0 \text{ (lb)}$$