


Elementary Statics

Equivalent Force Systems for Distributed Loads

- It is common for **structural** members to experience loads that are **distributed** along parts or all their length.
- The diagram shows a **simply supported beam** with **distributed load** $w(x)$. The units of $w(x)$ are pounds per foot (**lb/ft**) or Newtons per meter (**N/m**).
- To find the **external forces** acting on the beam shown at its supports at A and B , it is helpful to **replace** the distributed load by an **equivalent force system**.
- In this case, the **equivalent force system** is simply a **single resultant force** F_R acting at the **centroid** of the **area** under the load diagram.



$$F_R = \sum F = \int_0^L w(x) dx$$

- Because the resultant force can be moved along its line of action, we only need to find \bar{x} the **x-coordinate** of the centroid of the load area.

$$\bar{x} = \frac{\int_0^L x w(x) dx}{\int_0^L w(x) dx} = \frac{1}{F_R} \int_0^L x w(x) dx \quad \text{or} \quad \bar{x} F_R = \int_0^L x w(x) dx$$


- Here, the term $\bar{x} F_R$ represents the **moment** of the **resultant force** about point A , and the term $\int_0^L x w(x) dx$ represents the **sum** of the **moments** of the **distributed load** about point A .
- As mentioned in previous notes, if we are studying the **internal forces** within a body, we **cannot** use equivalent force systems to represent the external loads. We **must use** the forces and couple moments **as applied**.

Example: (using composite shapes)


Given: Beam loaded as shown

Find: Resultant F_R and its location relative to end A

Solution:



For the purpose of finding the resultant and its location, the applied load can be thought of having two parts, a constant distributed load of 1500 (N/m) and a triangular distributed load which increases from zero at A to 3000 (N/m) at B .



Constant distributed load:

$$F_1 = -6(1500) j = -9000 j = -9 j \text{ (kN)} \quad \text{acting at } \bar{x}_1 = 3 \text{ (m)} \text{ the midpoint of the beam}$$

Triangular distributed load:

$$F_2 = -\frac{1}{2}(6)(3000) j = -9000 j = -9 j \text{ (kN)} \quad \text{acting at } \bar{x}_2 = \frac{2}{3}(6) = 4 \text{ (m)}.$$

Total load:

$$F_R = \sum_{i=1}^2 F_i = -18000 j \text{ (N)} = -18 j \text{ (kN)}$$

$$\bar{x} = \frac{1}{F_R} (F_1 \bar{x}_1 + F_2 \bar{x}_2) = \frac{1}{18} (9(3) + 9(4)) = \frac{7}{2} = 3.5 \text{ (m)}$$